



PROCEDURE TO INSTALL TRANSITION

1. LAYOUT POINTS A, D, G, & H.
2. USE POINTS A & D TO DETERMINE A STRAIGHT LINE AND MARK B & C.
3. USE POINTS C & G TO DETERMINE A STRAIGHT LINE AND MARK E & F.
4. MARK J BY MEASURING 180 mm (7") IN FROM C;
MARK I BY MEASURING 150 mm (6") IN FROM G.
5. FORM CURVES B-J-E & F-I-H.
6. STRIPE.

CITY OF PASADENA - PUBLIC WORKS & TRANSPORTATION DEPARTMENT

DRAWN BY: *M.M.*
M. MOJICA

CHECKED BY:
D. ORTEGA *BO*

SUBMITTED BY
C. HERNANDEZ *CH*

**TURN BAY TRANSITION-
SINGLE
DOUBLE CENTERLINE**

APPROVED BY:
Bah...

DATE: *6/4/01*

TRANSPORTATION ADMINISTRATOR RTE NO. 1820 EXPIRES JUNE 30, 2005

REVISION: 1 UNITS: DUAL

STANDARD PLAN:
S-702

SHEET 1 OF 1
S702-1-REV.18MG 3/13/01